



A Material Difference

Mediprene[®]

Sterilization Tests

 **HEXPOL[®]**
TPE

CONTENTS

General Information About Sterilization Tests 

Gamma sterilization 

Ethylene Oxide Sterilization (EtO) 

Steam Sterilization (Autoclave) 

General Information about Sterilization Tests

Test specimens for tensile tests were punched out of plaques injection-moulded from Mediprene 500200M, Mediprene 500600M and Mediprene 500900M.

All mechanical test values refer to tensile testing of the material parallel with the flow direction. Changes reported in the tables in this guide have been calculated by comparing values for sterilized specimens with the corresponding values for the unsterilized reference.

Please [contact us](#) for further information.

Gamma Sterilization

Samples were radiated.

During the exposure period the samples were placed in test tubes. The temperature was not controlled, but approximately 30°C. Samples were taken out after two different dose levels; 25 kGy and 50 kGy and material property changes when compared with the unsterilized reference were determined.

Gamma Sterilization Results at 25 kGy Radiation Dose

Mediprene Grade	Hardness Change Shore A	Tensile Strength Change %	Stress at 100% Strain Change %	Stress at 300% Strain Change %	Elongation at Break Change %	Yellowness Index Change units
Test Method	ASTM D2240 (4mm)	ASTM D638	ASTM D638	ASTM D638	ASTM D638	ASTM D1925
500200M	-1.5	+29	-17	-15	+56	+5.5
500600M	0	+10	-10	-9	+24	+6.5
500900M	0	-11	-5	-5	-2	+10

Gamma Sterilization Results at 50 kGy Radiation Dose

Mediprene Grade	Hardness Change Shore A	Tensile Strength Change %	Stress at 100% Strain Change %	Stress at 300% Strain Change %	Elongation at Break Change %	Yellowness Index Change units
Test Method	ASTM D2240 (4mm)	ASTM D638	ASTM D638	ASTM D638	ASTM D638	ASTM D1925
500200M	-3	+58	-25	-25	+98	+9
500600M	-1.5	+10	-14	-12	+30	+10
500900M	+0.5	-17	-7	-8	-5	+13

Ethylene Oxide Sterilization (EtO)

Samples were ethylene oxide (EtO) sterilized with the following process set-up and material property changes when compared with the unsterilized reference were determined.

Sub-Process	Value
Initial deep vacuum end value	40 mbar
Humidification time at pressure 65 - 90 mbar	1 h 25 min
Relative humidity	> 50% RH
Gas concentration, pressure rise	From 68 mbar - 426 mbar
Sterilization pressure	425 - 435 mbar
Chamber temperature during sterilization phase	48.6 - 49.2°C
Sterilization time	3 h
Gas evacuation from sterilization pressure to 45 mbar	45 min
Gas evacuation, continued pressure reduction	1 h 40 min

Ethylene Oxide Sterilization Results

Mediprene Grade	Hardness Change Shore A	Tensile Strength Change %	Stress at 100% Strain Change %	Stress at 300% Strain Change %	Elongation at Break Change %	Yellowness Index Change units
Test Method	ASTM D2240 (4mm)	ASTM D638	ASTM D638	ASTM D638	ASTM D638	ASTM D1925
500200M	0	+2	+3	+2	+1	+1.5
500600M	+1	-4	+7	+4	-9	+1.5
500900M	+0.5	-3	+7	+4	-8	+2

Steam Sterilization (Autoclave)

Samples were steam sterilized with the process cycle described in the table below.

Samples were taken out after 1, 10, 25 and 50 cycles respectively and material property changes when compared with the unsterilized reference were determined.

SUB-PROCESS	TIME
Vacuum	3 minutes
Sterilization at 134°C	7 minutes
Vacuum	5 minutes

Steam sterilization results : Mediprene 500200M

Number of Cycles	Hardness Change Shore A	Tensile Strength Change %	Stress at 100% Strain Change %	Stress at 300% Strain Change %	Elongation at Break Change %
Test Method	ASTM D2240 (4mm)	ASTM D638	ASTM D638	ASTM D638	ASTM D638
1	-0.5	-10	-18	-19	+13
10	-1.5	-2	-20	-23	+31
25	-1.5	-7	-23	-23	+29
50	-2	-1	-22	-27	+40

Note that there might be dimensional stability limitations under steam sterilization conditions.

Please contact Hexpol TPE for further discussion

Steam sterilization results : Mediprene 500600M

Number of Cycles	Hardness Change Shore A	Tensile Strength Change %	Stress at 100% Strain Change %	Stress at 300% Strain Change %	Elongation at Break Change %
Test Method	ASTM D2240 (4mm)	ASTM D638	ASTM D638	ASTM D638	ASTM D638
1	+2	-1	+11	+13	-19
10	+1	+1	+11	+14	-18
25	+1	+3	+11	+14	-15
50	+1	+5	+14	+17	-15

Note that there might be dimensional stability limitations under steam sterilization conditions.

Please contact Hexpol TPE for further discussion

Steam sterilization results : Mediprene 500900M

Number of Cycles	Hardness Change Shore A	Tensile Strength Change %	Stress at 100% Strain Change %	Stress at 300% Strain Change %	Elongation at Break Change %
Test Method	ASTM D2240 (4mm)	ASTM D638	ASTM D638	ASTM D638	ASTM D638
1	+1.5	+5	+28	+29	-20
10	0	+6	+30	+34	-26
25	+1.5	+6	+33	+36	-29
50	+1.5	+7	+33	+37	-27

Note that there might be dimensional stability limitations under steam sterilization conditions.

Please contact Hexpol TPE for further discussion

More Mediprene TPE Ranges

Click for more information

Mediprene® 500M

Standard Series



Mediprene® 500M

Plunger Seal Series



Mediprene® A

2K

Mediprene® BM



Mediprene®



Mediprene® 500M

Transparent Series



Mediprene® OF



Mediprene®

Solvent Bondable



We provide written and illustrated advice in good faith. This should only be regarded as being advisory and does not absolve customers from doing their own full-scale tests to determine the suitability of the material for the intended applications. You assume all risk and liability arising from your use of the information and/or use or handling of any product. HEXPOL TPE makes no representations, guarantees, or warranties of any kind with respect to the information contained in this document about its accuracy, suitability for particular applications, or the results obtained or obtainable using the information. Figures are indicative and can vary depending on the specific grade selected and the production site. We retain the right to make changes without prior notice. HEXPOL and Dryflex are trademarks of HEXPOL Group, registered or used in many jurisdictions worldwide.